

Bruksanvisning Dörrklocka Duo

Två-tons dörrklocka för ringlednings-transformator 8V.

Tryckknapp med eller utan belysning kan användas.

1. Ta bort bakstycket genom att ta en spårskruvmejsel och försiktigt bryta loss framkåpan i det övre eller nedre hålet.
2. Montera upp bakstycket och koppla enligt schema till en ringledningstransformator.
3. Sätt tillbaka framkåpan genom att lätt trycka den på plats.

Observera att 230V inte får kopplas direkt till dörrklockan.

Käyttöohje ovikello Duo

Kaksiääninen muuntajakäyttöinen ovikello 8V.

Voidaan käyttää painiketta valolla tai ilman.

1. Irrota takalevy uraruuvitaltan avulla ja taivuta varovasti suojakansi irti ylemmästä tai alemmasta reiästä.
2. Aseta takalevy seinälle ja kytke ohjeen mukaisesti johtimet muuntajalle.
3. Paina suojakansi takaisin paikalleen.

Huomioi että 230V jännitettä ei saa kytkeä suoraan ovikelloon.

Manual Door Chime Duo

Two tone door chime for bell transformer 8V.

Push button with or without background light may be used.

1. With the use of a screwdriver, remove the back plate carefully.
2. Mount the back plate on the wall and connect the door chime to a bell transformer (see the wiring diagram at the next page).
3. Replace the front to the back plate, by pressing lightly on the front.

Do not connect 230V directly to the door chime.

MALMBERGS

