


# Vision Track L Pro/Vision Track L




# hidealite



| E-nr      | Snro      | El.nr     | GTIN          | Name                                 | Angle | LED color       | Color | Effect |
|-----------|-----------|-----------|---------------|--------------------------------------|-------|-----------------|-------|--------|
| 74 041 00 | 41 586 06 | 32 462 02 | 7392971151557 | Vision Track L 3-phase 20° White     | 20°   | 2700-6500K/RGBW | White | 30W    |
| 74 041 01 | 41 586 07 | 32 462 03 | 7392971152097 | Vision Track L 3-phase 44° White     | 44°   | 2700-6500K/RGBW | White | 30W    |
| 74 041 02 | 41 586 08 | 32 462 04 | 7392971151564 | Vision Track L 3-phase 20° Black     | 20°   | 2700-6500K/RGBW | Black | 30W    |
| 74 041 03 | 41 586 09 | 32 462 05 | 7392971152103 | Vision Track L 3-phase 44° Black     | 44°   | 2700-6500K/RGBW | Black | 30W    |
| 74 041 04 | 41 586 14 | 32 462 10 | 7392971151571 | Vision Track L 3-phase Pro 20° White | 20°   | 2700-6500K/RGBW | White | 30W    |
| 74 041 05 | 41 586 15 | 32 462 11 | 7392971152110 | Vision Track L 3-phase Pro 44° White | 44°   | 2700-6500K/RGBW | White | 30W    |
| 74 041 06 | 41 586 16 | 32 462 12 | 7392971151588 | Vision Track L 3-phase Pro 20° Black | 20°   | 2700-6500K/RGBW | Black | 30W    |
| 74 041 07 | 41 586 17 | 32 462 13 | 7392971152127 | Vision Track L 3-phase Pro 44° Black | 44°   | 2700-6500K/RGBW | Black | 30W    |




For explanation of symbols see [www.hidealite.se](http://www.hidealite.se) | [www.hidealite.com](http://www.hidealite.com) | [www.hidealite.fi](http://www.hidealite.fi) | [www.hidealite.no](http://www.hidealite.no) | [www.hidealite.dk](http://www.hidealite.dk)




## SAFETY INSTRUCTIONS

- en** Read these instructions carefully before commencing installation and retain for future reference. The luminaire should be installed by a licensed electrician and in accordance with local regulations. Make sure that the power is off before installation or maintenance.
- sv** Läs dessa instruktioner före installationen påbörjas och lämna den vidare till brukaren av anläggningen. Armaturen skall installeras av behörig installatör och enligt gällande föreskrifter. Se till att spänningen är frånslagen före installation eller underhåll.
- fi** Lue nämä ohjeet ennen asentamista ja luovuta ohjeet valaisimen seuraavalle käyttäjälle. Valaisimen saa asentaa valtuutettu asentaja voimassa olevien määräysten mukaisesti. Varmista, että jännite on kytketty päältä ennen asennusta ja huolto.
- no** Les disse instruksjonene før du starter installeringen, og gi den deretter videre til anleggets bruker. Armaturen skal installeres av en godkjent installatør og i henhold til gjeldende lover og regler. Sørg for at strømmen er koblet fra før installering og ved vedlikehold.
- da** Læs denne vejledning omhyggeligt, før installationen udføres og gem den til fremtidig brug. Armaturet skal installeres af en autoriseret installatør i henhold til gældende love og regler. Sørg strømmen er afbrudt før installation og vedligeholdelse.
- de** Lesen Sie diese Anweisungen sorgfältig, bevor Sie mit der Installation beginnen, und bewahren Sie sie für späteres Nachschlagen auf. Dieses Leuchtmittel muss durch einen lizenzierten Elektriker im Einklang mit den örtlichen Vorschriften installiert werden. Stellen Sie vor Installations- oder Wartungsarbeiten sicher, dass keine Spannung mehr anliegt.
- pl** Przed przystąpieniem do instalacji należy się uważnie zapoznać z instrukcją i zachować ją na przyszłość. Oprawę oświetleniową powinien zainstalować uprawniony elektryk zgodnie z miejscowymi przepisami. Przed instalacją lub konserwacją wyłączyć zasilanie.
- fr** Lisez attentivement ces consignes avant de commencer l'installation. Pensez également à vous y reporter ultérieurement. Le luminaire doit être installé par un électricien agréé, conformément à la réglementation locale. Veuillez à couper le courant avant l'installation et toute opération de maintenance.

## Download the App.



Non-replaceable control gear



Non-replaceable light source

## Terms of Use

### Information:

The camera function in this product is solely intended to gather color information of an object. This product or cloud service never saves image material; it is automatically deleted. When using the "AUTO" function, as a user, you can never see the product's last taken picture; it is immediately deleted.

### Terms:

The purpose of Tracklight is NOT to take pictures of people. When using the product and its functions, always ensure that no person is captured in the photo.  
-Alt 1: When using the "Take a picture" function, always ensure that no person is captured in the image.  
-Alt 2: When using the "View commodity position" function, always ensure that you are physically close to the product to ensure that no person is captured in the image.

Using the product for illegal purposes or in ways that violate applicable legislation or these Terms of Use is strictly prohibited.

Elektro Elco guarantees that personal information such as email address and name created in the application will be periodically cleansed from our cloud service. Elektro Elco is the data controller in our customer relationship and ensures this. Read more: <https://www.hidealite.com/sv-se/om-oss/policies>

Privacy and Data Protection - The use of the product may involve the collection and processing of personal data. If a person is captured in a photo, it is your responsibility to ensure that all such processing is in accordance with applicable data protection legislation, including GDPR where relevant.

Changes to the Terms - Elektro Elco reserves the right to change these Terms at any time. The latest version of the Terms will always be available on our web [www.hidealite.com](http://www.hidealite.com)

## Light setting mode

### There are three ways to set lighting

#### 1. Auto mode

- Auto mode is on by default. The track light senses commodity information and tune the light automatically to a professional formula library.
- Using auto mode, the sensor on the light will sense commodity information every 20 minutes by default.
- Using other light setting method, like take photo or customization, will turn auto mode off. Turn "Auto mode" on in APP if use auto mode again.
- Only Vision Pro have auto mode function


#### 2. Take photo

- Take a photo of target commodity or choose a photo from albums
- "Draw a box" or "tap" on the target color and the light will be changed accordingly.
- Auto mode will be turned off automatically.

#### 3. Customization

- Tap "Customization" on lighting setting page, user can tune the color, color temperature, saturation and brightness of the light.
- Auto mode will be turned off automatically.

## Installation



## Recycling

